











DRIVE SHAFT

SST

	09520-01010	Drive Shaft Remover Attachment	-
	09520-24010	Differential Side Gear Shaft Puller	-
	(09520-32040)	Shocker Set	-
	09527-10011	Rear Axle Shaft Bearing Remover	-
	09608-16042	Front Hub Bearing Adjusting Tool	-
	(09608-02021)	Bolt & Nut	-
	(09608-02041)	Retainer	-
	09710-04081	Base	-
	09726-40010	Lower Control Shaft Bearing Replacer	-
	09950-00020	Bearing Remover	-

EQUIPMENT

Dial indicator with magnetic base	
Micrometer	
Torque wrench	